

OMNI-DB-7-800/PCS

760-890 & 1850-1950 MHz

INSTALLATION:

- 1) INSERT THE ANTENNA CONNECTOR THROUGH THE HOLE IN THE MOUNTING BRACKET
- 2) PLACE THE LOCK WASHER OVER THE CONNECTOR
- 3) SCREW THE NUT ON THE CONNECTOR AND TIGHTEN
- 4) INSERT THE U-BOLTS THROUGH THE U-BOLT HOLES IN THE MOUNTING BRACKET
- 5) SLIDE THE ANTENNA AND BRACKET ASSEMBLY OVER THE MOUNTING PIPE AND TIGHTEN THE U-BOLTS

