



Cellular Mount Installation Considerations Trunk Lip Mount, Dual Band, UHF/CEL Antenna

TKLP-DB-UHF/CEL

VERIFY:


1. **Part List:** The package includes antenna, cable(s), coupler, connectors and hardware (See drawing). Use only the components supplied with the antenna. I.e. mast, couplers, and cables
2. **Bandwidth:** VHF/Cellular Broadband antennas are 20 MHz wide, within the range of 406-512 MHz, and 90 MHz wide between 806 and 896 MHz. Extended tuning ranges are available. Be certain that the antenna was tuned to the frequencies required.

INSTALLATION:

1. **Placement:** Select a desired location for the antenna; it may be mounted in the center of the trunk nearest to the rear window. If the antenna comes into contact with the window when raising the trunk lid, you may move it to either side of the trunk lid, away from the AM/FM radio antenna.

Note: Keep in mind that some vehicles will have aluminum or composite trunk lids.

2. **How to attach:** Route coaxial cable with TNC connector through raised trunk lid. Tilt mounting base and hook the clamp bracket on trunk lip, avoid pinching the cable.
3. **Interconnect:** Refer to the Dual Band Assembly Configuration Drawing. Do not tape or secure any feedlines to data or vehicle cables during installation. Remove red fit caps and connect the UHF radio to the port marked "UHF" and the Cellular device to the "800" port.



Dual Band Assembly Configuration Drawing



4. **Cable Cutting:** Cut the feedline cable to the appropriate length required to reach the transmitter. The feedline cable may be cut at any point between the duplexer unit and the transmitter.
5. **Install Connectors:** Refer to Cable Stripping Dimensions diagram.

TESTING:

Installation testing, if required, must take place at the transmitter side of the feedline. This will ensure that the cable connectors and cables have the proper continuity. Make sure all doors, hood, and trunk are closed. The duplexer can is part of the tuning network and needs to be in line for proper test results.

1. **Reflective Power:** A measurement of reflective power using a wattmeter, you can expect up to 11% reflected power. When results are greater than 11%, recheck grounding.
2. **SWR:** A measurement of SWR (standing wave ratio) will yield better than 2:1. If greater than 2:1, recheck grounding.

CAUTION: *The mast must be removed at the knurled portion of the mast assembly before entering a car wash.*